

Wanneer het zadel niet meer opent, bevindt zich aan de zijkant onder de buddyseat een witte connector/stekker.

Om het zadel te openen:

1. Zet tijdelijk 12 volt spanning op de connector
 - plus op de rode draad
 - min op de zwarte draad
2. Wacht enkele seconden.
3. Open tegelijkertijd het zadel met de sleutel.

Hierdoor ontgrendelt het zadelmanisme en kan het zadel worden geopend.

Op locatie gebruiken wij hiervoor het apparaat dat op onderstaande foto's is weergegeven.

Zie onderstaande foto's ter verduidelijking.

Foto 1: witte connector/stekker aan de zijkant onder de buddyseat

Foto 2: apparaat waarmee tijdelijk spanning op de connector wordt gezet

If the seat no longer opens, a white connector/plug is located on the side underneath the buddy seat.

To open the seat:

1. Temporarily apply 12 volts to the connector
 - plus on the red wire
 - minus on the black wire
2. Wait a few seconds.
3. At the same time, open the seat with the key.

This should unlock the seat mechanism and allow the seat to be opened.

On location, we use the device shown in the photos below to apply power to this connector.

Please see the attached photos for clarification.

Photo 1: white connector/plug on the side underneath the buddy seat

Photo 2: device used to temporarily apply power to the connector

